

TECHNICAL SPECIFICATIONS & MATERIAL PROPERTIES



UPVC/PVC PIPES & FITTINGS

Crown Plastic are exclusively available in the full range of uPVC/PVC pipes and fittings to meet the customer requirements and satisfaction. Crown Plastic products are suitable for various applications such as potable water line, irrigation, soil & waste water (above ground & below ground), drainage, ducting (electrical & tele communications) etc.

Crown Plastic pipes & fittings can solve many engineering problems whilst reducing overall costs because of their inherent properties of lightness, corrosion resistance and robustness. These coupled with precision manufacture will ensure maximum operational efficiency at economical laid costs.

Crown Plastic are manufacturing pipes and fittings according to various specifications of international standards like BS EN, DIN, BS, ISO, SASO, NEMA & ASTM etc.

QUALITY

Crown Plastic products are designed to meet the harsh climate conditions of the GCC region and places emphasis on Quality, Reliability and Economy.

Crown Plastic follow strict in-house Quality Control and backed by testing through independent laboratories of international repute to certify the quality of pipes and fittings.

Crown plastic do great emphasis on customer satisfaction through quality products. The company's operational excellence is evident through its established Quality management system which complies with ISO 9001 - 2015 standard, certified by Quality Accreditation Bureau for Qualified Companies (QAQC), USA.

RAW MATERIALS

The raw materials used is 100% uPVC virgin materials with necessary chemicals needed to facilitate the manufacturing process.

PHYSICAL APPEARANCE

The external and internal surface of the pipes and fittings are mirror smooth, clean and free from surface defects.

EFFECTIVE LENGTH

All pipes are manufactured in 4 meter and 6/5.8 meter length, custom length will provide according to the requirements.

COLOUR

The colour of Crown Plastic Products are available according to the standards and custom colour up on the requirements.

UPVC PIPES

S. No#	Characteristics	Value	Value
1.	Impact Strength	TIR <10% at 0°C	EN 744
2.	Vicat Softening Temperature	>80°C	EN 727
3.	Longitudinal Reversion	<5% at 150°C	EN 743 (Method B ; Air)
4.	Opacity	Shall not transmit >0.2% of visible light	EN 578
5.	Resistance to Internal Pressure	No failure the test period of 1hr at 20°C ; 42Mpa	EN 921
6	Resistance to Dichloromethane Test	No attack at any part of the surface of pipe at 15°C	EN 580

UPVC FITTINGS

S. No#	Characteristics	Value	Value
1.	Vicat Softening Temperature	>74OC	EN 727
2.	Opacity	Shall not transmit >0.2% of visible light	EN 578
3.	Resistance to Internal Pressure	No failure the test period of 1hr at 20°C ; 3.36 X PN	ISO/DIS 12092
4	Effects on Heating	Depth of crack/delamination, blisters or signs of weld line splitting <30% of wall thickness around injection point	EN 743 (Method B ; Air)

CHEMICAL RESISTANCE

uPVC pipes and fittings are suitable to be used with a number of acids, alkalies , salts and solvents that can be mixed with water.

uPVC pipes and fittings are not resistant to aromatic and chlorinated hydrocarbons.

Three different classes of chemical resistance degree are conventionally used in this guide ie:

- Class 1: **HIGH RESISTANCE** (corrosion-proof) - all materials belonging to this ely corrosion-proof against the conveyed fluid, according to the specified operating conditions.
- Class 2: **LIMITED RESISTANCE** - the materials belonging to this class are partially attacked by the conveyed chemical compound. The average life of the material is therefore shorter, and it is advisable to use a higher safety factor by selecting a higher SN rating pipe.
- Class 3: **NO RESISTANE** - all material belonging to this class are subject to corrosion by the conveyed fluid and they should therefore not be used.

The absence of any class indication means that no data are available concerning the chemical resistance of the material in respect of the conveyed fluid.

CHEMICAL RESISTANCE TABLE

uPVC Chemical Resistance Chart

ABBREVIATIONS

sat = saturated solution at 20°C, nd = undefined concentration,

deb = weak concentration, comm = commercial solution, dil = diluted solution

	FORMULA	CONC %	TEMP (°C)	PVC	PE		FORMULA	CONC %	TEMP (°C)	PVC	PE
ACETALDEHYDE	CH ₃ CHO	100	25 60	3 3	1	- FLUORIDE	NH ₄ F	25	25 60	1 2	1 1
- AQUEOUS SOLUTION		40	25 60	3 3	1	- HYDROXIDE	NH ₄ OH	28	25 60	- 2	1 1
ACETIC ACID	CH ₃ COOH	≤ 25	25 60	1 2	1 1	- NITRATE	NH ₄ NO ₃	sat	25 60	1 1	1 1
		30	25 60	1 2	1 1	- PHOSPHATE DIBASIC	NH ₄ (HPO ₄) ₂	all	25 60	1 1	1 1
		60	25 60	1 2	1 1	- PHOSPHAT META	(NH ₄) ₂ P ₂ O ₇	all	25 60	1 1	
		80	25 60	1 2	1 1	- PHOSPHATE TRI	(NH ₄) ₃ HPO ₄	all	25 60	1 1	
GLACIAL		100	25 60	2 3	1 2	- PERSULFATE	(NH ₄) ₂ S ₂ O ₈	all	25 60	1 1	
ACETIC ANHYDRIDE	(CH ₃ CO) ₂ O	100	25 60	3 3	2 2	- SULFIDE	(NH ₄) ₂ S	deb	25 60	1 2	1 1
ACETONE (DIMETHYL KETONE)	CH ₃ COCH ₃	10	25 60	3 3	1 2		sat	25 60	1 1	1 1	
		100	25 60	3 3	2 2	- SULFHYDRATE	NH ₄ OHSO ₄	dil	25 60	1 2	1 1
ACETOPHENONE (ACETYL BENZENE OR PHENYL METHYL KETONE)	CH ₃ COC ₆ H ₅	nd	25 60				sat	25 60	1 2	1 1	
ACRYLONITRILE (ACRYLONITRILE OR VINYL CYANIDE)	CH ₂ CHCN	technically pure	25 60	3	1 1	AMYLACETATE (PENTYL ACETATE)	CH ₃ CO ₂ CH ₂ (CH ₂) ₃ CH ₃	100	25 60	3	2
ADIPIC ACID	(CH ₂ CH ₂ CO ₂ H) ₂	sat.	25 60	1 2	1 1	AMYLALCOHOL	CH ₃ (CH ₂) ₃ CH ₂ OH	nd	25 60	1 2	1 1
AQUEOUS SOLUTION						ALANINE (PHENYLAMINE OR AMINOBENZENE)	C ₆ H ₅ NH ₂	all	25 60	3 3	2 2
ALLYL ALCOHOL	CH ₂ CHCH ₂ OH	96	25 60	2 3	1 2	- CHLORHYDRATE (ANILINE HYDROCHLORIDE)	CH ₆ H ₅ NH ₂ HCl	nd	25 60	2 3	2 2
ALUM	Al ₂ (SO ₄) ₃ ·xH ₂ O	dil dil sat.	25 60 60	1 2 2	1 1 1	ANTIMONY - TRICHLORIDE	SbCl ₃	100	25 60	1 1	1 1
ALUMINIUM - CHLORIDE	AlCl ₃	all	25 60	1 1	1 1	ANTHRACINONE (SULFONIC ACID)	suspension	25	1 60	1 2	-
- FLUORIDE	AlF ₃	100	25 60	1 1	1 1	AQUA REGIA	HCl+HNO ₃	100	25 60	2 2	3 3
- HYDROXIDE	Al(OH) ₃	all	25 60	1 1	-	ARSENIC ACID	H ₃ AsO ₄	deb	25 60	1 2	1 1
NITRATE	Al(NO ₃) ₃	nd	25 60	1 1	-		80	25 60	1 2	1 1	
SULFATE	Al(SO ₄) ₃	deb	25 60	1 1	1 1	BARIUM CARBONATE	BaCO ₃	all	25 60	1 1	1 1
		sat	25 60	1 1	1 1	- CHLORIDE	BaCl ₂	10	25 60	1 1	1 1
AMMONIA	NH ₃	deb	25 60	1 1	1 1	- HYDROXIDE	Ba(OH) ₂	all	25 60	1 1	1 1
- AQUEOUS SOLUTION		sat	25 60	1 1	1 1	- SULFATE	BaSO ₄	nb	25 60	1 1	1 1
- DRY GAS		100	25 60	1 1	1 1	- SULFIDE	BaS	sat	25 60	1 1	
- LIQUID		100	25 60	2 3	1 1	BEER		comm	25 60	1 1	1
AMMONIUM	CH ₃ COONH ₄	sat	25 60	- 2	1 1	BENZALDEHYDE	C ₆ H ₅ CHO	nd	25 60	3 3	2 2
- ACETATE	(NH ₄) ₂ CO ₃	all	25 60	1 2	1 1	CHLORAMINE	NH ₂ Cl	dil	25 60	1	1
- CARBONATE						CHLORIC ACID	HClO ₃	20	25 60	1 2	1 3
						CHLORINE	Cl ₂	sat	25 60	2 3	
BENZENE (BENZOL)	C ₆ H ₆	100	25 60	3 3	3	- DRY GAS		10	25 60	1 2	
+ LIGROIN		10/80	25 60	3 3			100	25 60	2 3		
- MONOCHLORINE	C ₆ H ₅ Cl	technically pure	25 60	3	2	- WET GAS		5 g/m3	25 60	1 3	
BENZOIC ACID	C ₆ H ₅ COOH	sat	25 60	1 2	1 1		10 g/m3	25 60	2 2	2	
BENZYL ALCOHOL	C ₆ H ₅ CH ₂ OH	100	25 60	1 2			65 g/m3	25 60	2 2	2	
BORIC ACID (BORACIC ACID)	H ₃ BO ₃	deb	25 60	1 2	1 1	- LIQUID		100	25 60	3	3
		sat	25 60	1 2	1 1						
BRINE		comm	25 60	1 1							
BROMIC ACID	HBrO ₃	10	25 60	1 1	1 1						

CHEMICAL RESISTANCE TABLE

uPVC Chemical Resistance Chart

	FORMULA	CONC %	TEMP (°C)	PVC	PE		FORMULA	CONC %	TEMP (°C)	PVC	PE
BROMINE - LIQUID - VAPOURS	Br ₂	100	25 60	3 3	3 3	CHLOROACETIC ACID	ClCH ₂ COH	85 100	25 60 25 60	1 2 3 3	2 3 3 3
BUTADIENE	C ₄ H ₆	100	25 60	1 1	3 3	CHLOROBENZENE	C ₆ H ₅ Cl	all	25 60	3 3	
BUTANEDIOL AQUEOUS	CH ₃ CH ₂ CHOHCH ₂ OH	10 concentrated	25 60 25 60	1 3 2 3	1 3 2 3	CHLOROFORM	CHCl ₃	all	25 60	3 3	2
BUTANE GAS	C ₄ H ₁₀	10	25 60	1 1	1 1	CHLOROSULPHONIC ACID	ClHSO ₃	100	25 60	2 3	3 3
BUTYL - ACETATE (BUTANATE) - ALCOHOL (BUTANOL)	CH ₃ CO ₂ CH ₂ CH ₂ CH ₂ CH ₃ C ₄ H ₉ OH	100	25 60	3 3	3 3	CHROME ALUM	KCr(SO ₄) ₂	nd	25 60	1 2	1 1
- PHENOL	C ₆ H ₅ OH	100	25 60	2 3	3 3	CHROMIC ACID	CrO ₃ +H ₂ O	10 30 50	25 60 25 60 25 60	1 2 2 3 2 3	2 3 1 2 2 3
BUTYLENE GLYCOL	C ₄ H ₈ (OH) ₂	100	25 60	2 1	1 1	CHROMIC SOLUTION	CrO ₃ +H ₂ O+H ₂ SO ₄	50/35/15	25 60	1 3	3 3
BUTYRIC ACID (BUTANOIC ACID)	C ₄ H ₇ CH ₂ COOH	20 concentrated	25 60 25 60	1 2 3 3	1 2 3 3	CITRIC ACID AQUEOUS min.	C ₃ H ₄ (OH)(CO ₂ H) ₃	50	25 60	1 1	1 1
CALCIUM - BISULFITE - CARBONATE	Ca(HSO ₃) ₂ CaCO ₃	nd	25 60	1 1	1 1	COPPER - CHLORIDE	CuCl ₂	sat	25 60	1 1	1 1
- CHLORATE	CaHClO ₃	nd	25 60	1 1	1 1	- CYANIDE	CuCN	all	25 60	3 3	
- CHLORIDE	CaCl ₂	all	25 60	1 2	1 1	- FLUORIDE	CuF ₂	all	25 60	1 1	1 1
- HYDROXIDE	Ca(OH) ₂	all	25 60	1 1		- NITRATE	Cu(NO ₃) ₂	nd	25 60	1 2	1 1
- HYPOCHLORITE	Ca(OCl) ₂	sat	25 60	2 1	1 1	- SULFATE	CuSO ₄	dil sat	25 60 25 60	1 1 1 1	1 1 1 1
- NITRATE	Ca(NO ₃) ₂	50	25 60	1 1	1 1	COTTONSEED OIL		comm	25 60	1 1	
- SULFATE	CaSO ₄	nd	25 60	1 1	1 1	CRESOL (HYDROXY TOLUENE)	CH ₃ C ₆ H ₄ CH ₃	≤90 ≥90	25 60 25 60	2 3 3 3	1 2 3 3
- SULFIDE	CaS	sat	25 60	1 2	2 2	CRESYLIC ACID	CH ₃ CH ₂ CH ₂ COOH	50	25 60	2 3	
CAMPOR OIL		nd	25 60	1 3	3 3	CYCLOHEXANE	C ₆ H ₁₂	all	25 60	3 3	1
CARBON - DIOXIDE AQUEOUS SOLUTION - GAS	CO ₂	- 100	25 60 25 60	1 2 1 1	1 1 2 2	CYCLOHEXANONE	C ₆ H ₁₀ O	all	25 60	3 3	1
- DISULFIDE	CS ₂	100	25 60	2 3	2 3	DECAHYDRONAPHTALENE	C ₁₀ H ₈	nd	25 60	1 1	1 2
- MONOXIDE	CO	100	25 60	1 1	1 1	DEMIMERALIZED WATER		100	25 60	1 1	1 1
- TETRACHLORIDE	CCl ₄	100	25 60	2 3	2 3	DIBUTYLPHALATE	C ₆ H ₄ (CO ₂ C ₄ H ₉) ₂	100	25 60	3 3	3 3
CARBONIC ACID - AQUEOUS SOLUTION - DRY	H ₂ CO ₃	sat 100	25 60 25 60	1 1 1 1		DICHLORO- ACETIC ACID	Cl ₂ CHCOOH	100	25 60	1 2	1 2
- WET		all	25 60	1 2		DICHLOROETHANE (ETHYLENE DICHLORIDE)	CH ₂ ClCH ₂ Cl	100	25 60	3 3	3 3
CARBON OIL		comm	25 60	1 1		DICHLOROETHYLENE	Cl(CH ₂) ₂ Cl	100	25 60	3 3	3 3
DIOCTYLPHTHALATE		all	25 60	3 3	1 2	DIETHYL ETHER	C ₂ H ₅ OC ₂ H ₅	100	25 60	3 3	3 3
DISTILLED WATER		100	25 60	1 1	1 1	DIGLYCOLIC ACID	(CH ₂) ₂ O(CO ₂ H) ₂	18	25 60	1 2	1 1
DRINKING WATER		100	25 60	1 1	1 1	DIMETHYLAMINE	(CH ₃) ₂ NH	100	25 60	2 3	2 2
ETHERS		all	25 60	3 3		HYDROCHLORIC ACID (MURIATIC ACID)	HCl	≤25 ≤37	25 60 25 60	1 2 1 1	1 1 1 2
ETHYL - ACETATE (ACETIC ETHER) - ALCOHOL	CH ₃ CO ₂ C ₂ H ₅ CH ₃ CH ₂ OH	100	25 60	3 3	1 3	HYDROCYANIC ACID (PRUSSIC ACID OR HYDROGEN CYANIDE)	HCN	deb	25 60	1 1	1 1
(ETHANOL) - CHLORIDE	CH ₃ CH ₂ Cl	all	25 60	3 3	2 3	HYDROFLUORIC ACID	HF	30	25 60	1 2	1 1
- ETHER	CH ₃ CH ₂ OCH ₂ CH ₃	all	25 60	3 3		HYDROGEN	H ₂	all	25 60		
ETHYLENE	ClCH ₂ CH ₂ OH	100	25	3		HYDROGEN - PEROXIDE (BLEACH)	H ₂ O ₂	30 50	25 60 25 60	1 1 1 2	1 1 1 -
						- SULFIDE DRY		sat	25 60	1 2	1 1

CHEMICAL RESISTANCE TABLE

uPVC Chemical Resistance Chart

	FORMULA	CONC%	TEMP (°C)	PVC	PE		FORMULA	CONC%	TEMP (°C)	PVC	PE
ETHYLENE	$\text{CICH}_2\text{CH}_2\text{OH}$	100	25	3		- SULFIDE WET		sat	25	1	1
- CHLOROHYDRIN			60	3					60	2	1
- GLYCOL	$\text{HOCH}_2\text{CH}_2\text{OH}$	comm	25	1	1	HYDROSULPHITE		≤10	25	1	1
(ETHANEDIOL OR GLYCOL)			60	1	3				60	2	
FATTY ACIDS		nd	25	1		HYDROXYLAMINE	$(\text{H}_2\text{NOH})_2\text{H}_2\text{SO}_4$	12	25	1	1
FERRIC	FeCl_3	10	25	1		SULPHATE			60	1	
- CHLORIDE		sat	25	1	1	ILLUMINATING		100	25	1	1
			60	2		GAS			60		
- NITRATE	$\text{Fe(NO}_3)_3$	nd	25	1	1	IODINE	I_2	3	25	2	
			60	1	1	- DRY AND WET			60	3	
- DEXTRINE (BRITISH GUM	$\text{C}_6\text{H}_{12}\text{OCH}_2\text{O}$	nd	25	1	1	- TINCTURE		≤3	25	2	2
OR STARCH GUM)			60	2	1				60	3	3
- SULFATE	FeSO_4H_3	nd	25	1	1	ISOCTANE	C_8H_{18}	100	25	1	2
			60	2	1				60		
FERROUS	FeCl_2	sat	25	1	1	ISO-OCTANE	$(\text{CH}_3)_2\text{CCH}_2(\text{CH}_3)_2$				
- CHLORIDE			60	1	1	ISOPROPYL	$(\text{CH}_3)_2\text{CHOCH}(\text{CH}_3)_2$	100	25	2	2
- SULFATE	FeSO_4	nd	25	1	1	- ETHER			60	3	3
			60	1	1	- ALCOHOL	$(\text{CH}_3)_2\text{CHOH}$	100	25		
FERTILIZER		≤10	25	1	1	(ISOPROPANOL)			60	2	
			60	1	1	LACTIC ACID	$\text{CH}_3\text{COHCOOH}$	≤28	25	1	1
		sat	25	1	1				60	2	1
			60	1	1			nd	25	1	1
FLUORINE GAS	F_2	100	25	2	2	LANOLINE			60	2	1
FLUOSILICIC ACID	H_2SiF_6	32	25	1	1	LEAD ACETATE	$\text{Pb}(\text{CH}_3\text{COO})_2$	sat	25	1	1
			60	3	3				60	1	-
FORMALDEHYDE	HCOH	-	25	1	1	LINSEED OIL		comm	25	1	2
			60	2	1				60	2	2
FORMIC ACID	HCOOH	50	25	1	1	LUBRICATING OILS		comm	25	1	3
		100	25	1	1				60	1	
			60	3	1	MAGNESIUM	MgCO_3	all	25	1	
FRUIT PULP AND JUICE		comm	25	1	1	- CARBONATE			60	1	
			60	1	1	- CHLORIDE	MgCl_2	sat	25	1	1
FUEL OIL		100	25	1					60	1	1
		comm	25	1	-	- HYDROXIDE	Mg(OH)_2	all	25	1	
			60	1	2				60	1	
FURFUROLE	$\text{C}_5\text{H}_3\text{OCH}_2\text{OH}$	nd	25	3	2	- NITRATE	MgNO_3	nd	25	1	1
ALCOHOL			60	3	2				60	1	1
GAS EXHAUST		all	25	1		- SULFATE	MgSO_4	dil	25	1	1
- ACID			60	1				sat	25	1	1
- WITH NITROUS		traces	25	1	1				60	1	1
- VAPOURS		60	1	1		MALEIC ACID	COOHCHCHCOOH	nd	25	1	1
GAS PHOSGENE	ClCOCl	100	25	1	2				60	1	1
			60	1	2	MALIC ACID	$\text{CH}_2(\text{COOH})(\text{COOH})_2$	nd	25	1	1
GELATINE		100	25	1	1	(HYDROXYSUCCINIC ACID)			60	-	-
			60	1	-	MERCURIC	HgCl_2	sat	25	1	1
GLUCOSE	$\text{C}_6\text{H}_{12}\text{O}_6$	all	25	1	1	- CHLORIDE			60	1	1
(DEXTROSE)			60	2	1	- CYANIDE	HgCN_2	all	25	1	
GLYCERINE	$\text{HOCH}_2\text{CH(OH)CH}_2\text{OH}$	all	25	1	1				60	1	
AQUEOUS (GLYCEROL)			60	1	1	MERCUROUS	HgNO_3	nd	25	1	1
GLYCOGLUE		10	25	1	1	NITRATE			60	1	1
AQUEOUS			60	1	1	MERCURY	Hg	100	25	1	1
GLYCOLIC ACID	HOCH_2COOH	37	25	1	1				60	2	1
			60	1	1	METHYL	$\text{CH}_3\text{COOCH}_3$	100	25	-	-
HEPTANE	C_7H_{16}	100	25	1	1	- ACETATE			60	-	-
			60	2	3	- ALCOHOL (METHANOL	CH_3OH	nd	25	1	1
HEXANE	C_6H_{14}	100	25	1	1	OF WOODSPIRIT)			60	1	1
			60	2	2	- BROMIDE	CH_3Br	100	25	3	3
HYDROBROMIC ACID	HBr	≤10	25	1	1	(BROMOMETHANE)			60		
		48	25	1	1	- CHLORIDE	CH_3Cl	100	25	3	1
			60	2	1	(CHLOROMETHANE)			60	3	
METHYLENE CHLORIDE	CH_2Cl_2	100	25	3	3	- ETHYLKETONE	$\text{CH}_3\text{COCH}_2\text{CH}_3$	all	25	3	1
(DICHLOROMETHANE)			60	3					60	3	2
METHYLSULPHURIC ACID	$\text{CH}_3\text{COOSO}_4$	50	25	1	2	METHYLAMINE	CH_3NH_2	32	25	2	1
		100	25	1	3				60	3	2
			60	2	3			≤85	25	1	1
MILK		100	25	1	1	- AMMONIUM	P_2O_5	nd	25	1	1
			60	1					60	2	1
MINERALACIDULOUS		nd	25	1	1	PHOSPHORUS	PO_3	100	25	3	1
WATER		comm	25	1	1	TROCHLORIDE			60	3	
MOLASSES			60	1	1	PHOTOGRAPHIC		comm	25	1	
NAPHTA		100	25	2	2	- DEVELOPER			60	1	
			60	3	3	- EMULSION		comm	25	1	1
NAPHTHALENE		100	25	1	1				60	1	
			60	2		PHTHALICACID	$\text{C}_6\text{H}_4(\text{CO}_2\text{H})_2$	50	25	-	1
			60	3	1				60	3	1
			60	3	1	PICRICACID	$\text{HOC}_6\text{H}_2(\text{NO}_2)_3$	1	25	1	1
			60	2					60	1	-
			60	3	1	(2,4,6-TRINITROPHENOL)		≥1	25	3	1
			60	3					60	3	

CHEMICAL RESISTANCE TABLE

uPVC Chemical Resistance Chart

	FORMULA	CONC %	TEMP (°C)	PVC	PE		FORMULA	CONC %	TEMP (°C)	PVC	PE
NICKEL - CHLORIDE	NiCl ₃	all	25 60	1 1	1 1	POTASSIUM - BICROMATE (POTASSIUM HYDROGENCARBONATE)	K ₂ Cr ₂ O ₇	40	25 60	1 1	1 1
- NITRATE	Ni(NO ₃) ₂	nd	25 60	1 1	1 1	- BORATE	K ₃ BO ₃	sat	25 60	1 2	
- SULFATE	NiSO ₄	dil sat	25 60 25 60	1 1 1 1	1 2 1 1	- BROMATE	KBrO ₃	nd	25 60	1 2	
NITRIC ACID	HNO ₃	anhydrous 20 40 60 98	25 60 25 60 25 60	3 3 1 2 3 3 3 3		- BROMIDE KBr		sat	25 60	1 1	1 1
NITROBENZENE	C ₆ H ₅ NO ₂	all	25 60	3 2		- CARBONATE (POTASH)	K ₂ CO ₃	sat	25 60	1 1	1 1
OLEIC ACID	C ₁₈ H ₃₃ O ₂	comm	25 60	1 2		- CHLORIDE (POTASSIUM MURIATE)	KCl	sat	25 60	1 1	1 1
OLEUM (FUMING SULPHURIC ACID OR PYROSULPHURIC ACID)	H ₂ S ₂ O ₇	nd	25 60	3 3		- CHROMATE	K ₂ CrO ₄	40	25 60	1 1	1 1
- VAPOURS	low high	25 3 60 25 60	3 3 3 3			- CYANIDE	KCN	sat	25 60	1 1	1 1
OLIVE OIL	comm	25	60	2	3	- FERROCYANIDE	K ₄ Fe(CN) ₆ H ₂ O	100	25 60	1 1	1 1
OXALIC ACID	HO ₂ CCO ₂ H	10 sat	25 60 25 60	1 1 1 1		- FLUORIDE	KF	sat	25 60	1 1	
OXYGEN	O ₂	all	25 60	1 2		- HYDROXIDE (CAUSTIC POTASH)	KOH	≤60	25 60	1 2	1 1
OZONE	O ₃	nd	25 60	1 2		- NITRATE KNO ₃ (NITRE, SALTPETRE)	sat	25 60	1 1	1 1	
PALMITIC ACID	CH ₃ (CH ₂) ₁₄ COOH	10 70	25 60 25 60	1 1 1 1		- FERBORATE	KBO ₃	all	25 60	1 1	
PARAFFIN (ALKANE)		nd	25 60	2 2		- FERMANGANATE (PERMANGANATE OF POTASH)	KMnO ₄	10	25 60	1 1	1 1
- EMULSION		comm	25 60	1 2		- FERSULFATE	K ₂ S ₂ O ₈	nd	25 60	1 2	1 1
- OIL (KEROSENE)		nd	25 60	1 1		- SULFATE	K ₂ SO ₄	sat	25 60	1 2	1 1
PERCHLORIC ACID	HClO ₄	100 70	25 60 25 60	1 1 1 2		PROPANE - GAS	C ₃ H ₈	100	25 60	1 1	1 1
PETROL		100	25 60	1 1		- LIQUID		100	25 60	1 1	2
- REFINED		100	25 60	1 1		PROPYL ALCOHOL (PROPANOL)	C ₃ H ₇ OH	100	25 60	1 2	1 1
- UNREFINED		100	25 60	1 1		PYRIDINE	CH ₃ CHCH ₃	nd	25 60	3 3	1 2
PHENOL	C ₆ H ₅ OH	1	25 60	1 1		RAIN WATER		100	25 60	1 1	1 1
- AQUEOUS SOLUTION (CARBOLIC ACID)		≤90	25 60	2 3	1	SEA WATER		100	25 60	1 1	1 1
PHENYL HYDRAZINE	C ₆ H ₅ NHNH ₂	all	25 60	3 2		SILICIC ACID	H ₂ SiO ₃	all	25 60	1 1	1 1
- CHLORHYDRATE	C ₆ H ₅ NHNH ₂ ·3Cl	sat	25 60	1 3		SILICONE OIL		nd	25 60	1 3	1 2
PHOSPHORIC - ACID	H ₃ PO ₄	≤25 ≤50	25 60 25 60	1 1 1 1		SILVER - CYANIDE	AgCN	all	25 60	1 1	
BICARBONATE/SODIUM HYDROGEN CARBONATE	NaHCO ₃	nd 60	25 60	1 1	1	- NITRATE	AgNO ₃	nd	25 60	1 2	1 1
- BISULFITE	NaHSO ₃	100	25 60	1 1		- PLATING SOLUTION		comm	25 60	1 1	
- BROMIDE	NaBr	sat	25 60	1 1		SOAP - AQUEOUS SOLUTION		high	25 60	1 2	
- CARBONATE	Na ₂ CO ₃	sat	25 60	1 1	1	SODIC LYE		≤60	25 60	1 1	
- CHLORATE	NaClO ₃	nd	25 60	1 2	1	SODIUM - ACETATE	CH ₃ COONa	100	25 60	1 1	1 1
- CHLORIDE	NaCl	dil sat	25 60 25 60	1 2 1 1		- FUMING (OLEUM)		60 all	3 25 60	2 2 2	
						- NITRIC AQUEOUS SOLUTION	H ₂ SO ₄ + HNO ₃ + H ₂ O	48/49/3 50/50/0 10/20/70	25 60 25 60	1 2 3 3 1 2	3 3 3 3 2 2
						TALLOW EMULSION		comm	25 60	1 1	1 2
						TANNIC ACID	C ₁₄ H ₂₀ O ₉	10	25 60	1 1	1 1
						TARTARIC ACID	HOOC(CHOH) ₂ COOH	all	25 60	1 2	1 1

CHEMICAL RESISTANCE TABLE

uPVC Chemical Resistance Chart

	FORMULA	CONC %	TEMP (°C)	PVC	PE		FORMULA	CONC %	TEMP (°C)	PVC	PE
- CYANIDE	NaCN	all	25 60	1 1		TETRACHLORO - ETHANE	CHCl ₂ CHCl ₂	nd	25 60	3 3	2 3
- FERROCYANIDE	Na ₄ Fe(CN) ₆	sat	25 60	1 1	1	- ETHYLENE (PERCHLOROETHYLENE)	CCl ₂ CCl ₂	nd	25 60	3 3	2 3
- FLUORIDE	NaF	all	25 60	1 1	1	TETRAETHYLLEAD	Pb(C ₂ H ₅) ₄	100	25 60	1 2	1 1
- HYDROXIDE	NaOH	60	25 60	1 1	1	TETRAHYDROFURAN	C ₄ H ₈ O	all	25 60	3 3	2 3
- HYPOCHLORITE	NaOCl	deb	25 60	1 2	1	THIONYL CHLORIDE	SOCl ₂	-	25 60	3 3	3
- HYPOSULFITE	Na ₂ S ₂ O ₃	nd	25 60	1 1		THIOPHENE	C ₄ H ₄ S	100	25 60	3 3	2 2
- NITRATE	NaNO ₃	nd	25 60	1 1	1	TOLUENE	C ₆ H ₅ CH ₃	100	25 60	3 3	2 3
- PERBORATE	NaBO ₃ H ₂ O	all	25 60	1 1		TRANSFORMER OIL		nd	25 60	1 2	1 2
- PHOSPHATE di	Na ₂ HPO ₄	all	25 60	1 1		TRICHLORO- ACETIC ACID	CCl ₃ COOH	≤50	25 60	1 3	1 2
- PHOSPHATE tri	Na ₃ PO ₄	all	25 60	1 1	1	TRICHLOROETHYLENE	Cl ₂ CClCl	100	25 60	3 3	2 2
- SULPHATE	Na ₂ SO ₄	dil sat	25 60 25 60	1 1 1 1		TRIETHANOLAMINE	N(CH ₂ CH ₂ OH) ₃	100	25 60	2 3	1 1
- SULFIDE	Na ₂ S	dil sat	25 60 25 60	1 2 1 1		TURPENTINE		100	25 60	2 2	2 3
- SULFITE	NaSO ₃	sat	25 60	1 1		UREA AQUEOUS SOLUTION	CO(NH ₂) ₂	≤ 10 33	25 60 25 60	1 2 1 1	1 1 1 1
STANNIC CHLORIDE	SnCl ₄	sat	25 60	1 1	1	URINE		nd	25 60	1 2	1 1
STANNOUS CHLORIDE	SnCl ₂	dil	25 60	1 1	1	URIC ACID	C ₅ H ₄ N ₄ O ₃	10	25 60	1 2	
STEARIC ACID	CH ₃ (CH ₂) ₁₆ CO ₂ H	100	25 60	1 2		VASELINE OIL		100	25 60	1 3	1 2
SUGAR SYRUP		high	25 60	1 2	1	VINYLACETATE	CH ₃ CO ₂ CHCH ₂	100	25 60	3 3	
SULPHUR	S	100	25 60	1 2		WHISKEY		comm	25 60	1 1	
- DIOXIDE AQUEOUS	SO ₂	sat	25 60	1 2	1	WINES		comm	25 60	1 1	1
- DIOXIDE DRY		all	25 60	1 1	1	WINE VINEGAR		comm	25 60	1 2	1 1
- DIOXIDE LIQUID		100	25 60	2 3	2	ZINC - CHLORIDE	ZnCl ₂	dil sat	25 60 25 60	1 1 1 1	1 1 1 1
- TRIOXIDE	SO ₃	100	25 60	2 3	3	- CHROMATE	ZnCrO ₄	all	25 60	1 1	
SULPHURIC ACID	H ₂ SO ₄	≤ 10 ≤ 75 ≤ 80 25 ≤ 96	25 60 25 60 25 60	1 1 1 2 2 2	1 1 1 2 2 2	- CYANIDE	Zn(CN) ₂	all	25 60	1	
						- NITRATE	Zn(NO ₃) ₂	nd	25 60	1	
						- SULFATE	ZnSO ₄	dil sat	25 60 25 60	1 1 1 1	1 1 1 1



CROWN PLASTIC

مصنع كراون للأنابيب البلاستيكية ذ.م.م
CROWN PLASTIC PIPES FACTORY LLC

PVC | UPVC | PPR | PEX | HDPE

P.O.Box:63576, U.A.E | Tel:00971 6 543 6781 | Fax:00971 6 543 6798
Email : info@crownplasticuae.com | Website : www.crownplasticuae.com